



# Galvanic Isolator

## Gi-Ultra

The Galvanic isolator protects the hull of your boat from corrosion caused by Galvanic currents that may arise due to chemical interactions between your boat and nearby boats/structures and bank-side.

It is only necessary to use a Galvanic isolator when you are connected to shore (mains) power. It is not necessary when you are using a generator or other power source that is not connected to Earth. Ensure that no ground connections on the vessel bypass the Galvanic isolator.



The Galvanic Isolator simply connects to EITHER end of your shore line. It can be connected either at the boat end or the shore end. Both options work equally well.

Locate your isolator where it will not be subjected to excessive heat, physical damage or water ingress, particularly the plugs & sockets.

When installed, to avoid water ingress, we strongly advise that the cable entries to the plug & socket should point downwards



- 1) Switch off the electricity supply at the shore supply.
- 2) Unplug the shore line from whichever end you choose.
- 3) Connect the isolator to the now free end of the shore line.
- 4) Connect the free end of the isolator to the boat/shore supply.
- 5) Switch on the electricity supply at the shore supply.
- 6) Check that the RCD test button on the boat operates normally
- 7) You are now protected. No further action is required.

Note:  
This isolator is suitable for shore supplies that are protected by an RCD (Earth Leakage Circuit Breaker) with a trip current not exceeding 30mA, and an MCB (Circuit breaker) not exceeding 16A if supplied fitted with 16A plugs, or 32A if supplied fitted with 32A plugs.

### IMPORTANT:

To prevent water ingress, before installation, and periodically, check Gland Nuts on both ends for tightness (Blue in photo). They should be as tight as possible USING HAND FORCE ONLY.

